



Chrome Shower Accessory Kit – 600 mm

INSTALLATION INSTRUCTIONS



Please read all instructions before installation and leave this document with the end user for future reference as it contains important warranty information

Parts Supplied



	Parts	QTY
A	2 m Shower Hose* (21-005-097)	1
B	Shower Handset* (21-005-108)	1
C	Slider	1
D	Hose Retainer	1
E	Wall Brackets	2
F	Riser Rail	1
G	Screw and Wall Plug	2



Before you start












Please remove all protective covering and examine carefully. Check that all items are present before discarding of any packaging.

Please notify the retailer immediately of any damage or faults. The manufacturer cannot be held responsible for any installation costs that may arise from damaged or faulty products being installed and not in accordance with these instructions. Please dispose all packaging in accordance with the local recycling authorities.

The shower kit positioning must comply with the latest water and building regulations, and should be in accordance with BS6700.


Safety

- Have the correct tools available.
- Fixings provided are suitable for solid walls only. Plasterboard or stud walls may require specialist fixings.
- When drilling into walls, check first for hidden pipes and cables.
- Use safety eye wear when drilling.
- Keep children away from the installation and away from small parts and packaging.



- 1 Determine the vertical position. Mark and drill top & bottom holes in the wall and fix bottom bracket to the wall.
- 2 Attach bracket cover.
- 3 Slide (F) into (C), (D) & (E).
- 4 Slide (F) into top bracket, screw & attach bracket cover.
- 5 Screw the shower hose (A) onto shower or mixer ensuring the washer is in the shower hose end.
- 6 Screw the shower hose (A) onto the shower head (B).
- 7 Locate shower handset (B) into holder and adjust height.
- 8 Adjust position and spray pattern.

Dimensions



Contact Us

AKW[®]
Life Made Better

Orders & Quotes

01905 823 299
orders@akw-ltd.co.uk

General Enquiries

01905 823 298
sales@akw-ltd.co.uk

Technical Enquiries

01905 560 219
tech@akw-ltd.co.uk

Kitchen Enquiries

01905 823 262
kitchens@akw-ltd.co.uk

Fax

01905 823 297

AKW

Pointon Way, Hampton Lovett
Droitwich Spa, WR9 0LR

www.akw-ltd.co.uk
orders.akw-ltd.co.uk

Follow us on Social:



Warranty

Warranty applies only to manufacturing or material defects, conditional on the one-time correct installation of the product. It does not apply to:

- Inappropriate use or accidental damage.
- Damage or defects that result from incorrect installation.
- Lack of maintenance including the build up of grime or damage resulting from inappropriate cleaning.
- Damage or defects that result from repairs or modifications undertaken by unauthorised persons.
- General wear and tear through usage and does not apply to surface finishes.

Warranty period starts from the date of installation. See the T&Cs on our website for further information.

Select 1 of 2 ways to activate your warranty



1. Scan using your Smart Device



2. Visit Online

akw-ltd.co.uk/warranty-information

What to do if something goes wrong?

In the event that you encounter a problem with this product, follow the trouble shooting guide if applicable, then contact your local installer. If the issue is still unresolved, contact AKW Technical Enquiries who will provide further advice and arrange for a maintenance engineer to visit if necessary. None of the foregoing affects your statutory rights.